

YTP NO.	TOYOTA(13101-)	ENGINE	Bore Dia	No. of Cyl.	PIN
YTTO070001	10033	1E	70.5	4	18*59
YTTO073001	11040	2E	73	4	18*59
YTTO073002	11050/1	2E	73	4	18*59
YTTO073003	11081	3E	73	4	18*59
YTTO073004	11030/90	2E	73	4	18*59
YTTO074001	55020	1N	74	4	23.5*58
YTTO074002	11101	4E	74	4	18*59
YTTO074003	11131/0,11161	5E	74	4	18*59
YTTO075001	13020/1/2	4K	75	4	18*61
YTTO075002	24010	3K	75	4	18*61
YTTO075003	24011	3K	75	4	18*61
YTTO076001	14020	2A	76	4	18*61
YTTO077001	15020	3A	77.5	4	18*61
YTTO078001	15040	5AF	78.7	4	18*61
YTTO080001	13030	5K	80.5	4	18*61
YTTO080002	31020/1/2	12R	80.5	4	20*66
YTTO080003	63010/20	1S	80.5	4	20*66
YTTO081001	16010	4A	81	4	18*61
YTTO081002	16090/16110	4A-FE	81	4	18*61
YTTO081003	16200/1	4A-G	81	4	20*56
YTTO081004	16160	4A	81	4	20*56
YTTO081005	16150	7A	81	4	20*56
YTTO082001	74071	4S-FE	82.5	4	20*66
YTTO082002	74160	4S	82.5	4	22*66
YTTO083001	64010/20	1C	83	4	27*68
YTTO083002	64040	1CT	83	4	27*68

YTP NO.	TOYOTA(13101-)	ENGINE	Bore Dia	No. of Cyl.	PIN
YTTO083003	64050/64100	1C	83	4	27*58
YTTO084001	37010/30/60	21R	84	4	22*72
YTTO084002	74010	2S	84	4	20*66
YTTO085001	26031	2T	85	4	22*66
YTTO086001	64070	2CT	86	4	27*58
YTTO086002	64080	2CT	86	4	27*58
YTTO086003	64090	2CT	86	4	27*58
YTTO086004	64110/1,64140/1	2C	86	4	27*58
YTTO086005	64120/1	2CT	86	4	27*61
YTTO086006	64150/1	3C	86	4	27*58
YTTO086007	71010	1Y	86	4	22*66
YTTO086008	72010	2Y	86	4	22*66
YTTO086009	73010	3Y	86	4	22*66
YTTO086010	74040	3S-FE	86	4	22*66
YTTO086011	75010	1RZ	86	4	24*61
YTTO086012	74100/70	3S-FE	86	4	22*66
YTTO086013	64030	2CB	86	4	27*68
YTTO086014	78201	1DZ	86	4	27*68
YTTO087001	74130/03030/74080	5S	87	4	22*66
YTTO087002	74220	5S	87	4	22*66
YTTO088001	44011/2/3/4/5/6	5R	88	4	22*75
YTTO088002	34030	18R	88.5	4	22*75
YTTO090001	54010/12	L(OLD)	90	4	27*74
YTTO090002	54020/1	L(NEW)	90	4	27*74
YTTO090003	54040	L	90	4	27*74
YTTO091001	68010	2H	91	6	29*74

YTP NO.	TOYOTA(13101-)	ENGINE	Bore Dia	No. of Cyl.	PIN
YTTO091002	73030/1	4Y	91	4	22*66
YTTO091003	73040	4Y	91	4	22*66
YTTO092001	35030/1/2,35070	22R	92	4	22*70
YTTO092002	54030	2L-TE	92	4	29*74
YTTO092003	54060	2L	92	4	27*74
YTTO092004	54070	2L(NEW)	92	4	27*70
YTTO092005	54080	2L-T	92	4	29*74
YTTO092006	54090/1	2L-TII	92	4	29*70
YTTO092007	35010/20	22R	92	4	22*75
YTTO094001	17010	1HZ 1PZ	94	6/5	29*65
YTTO094002	61010/1	2F	94	6	25.15*72
YTTO094003	61030/1	3F	94	6	22*75
YTTO094004	17040	1HD-T	94	6	33*73
YTTO095001	56011	B(OLD)	95	4	29*79
YTTO095002	56020/1,30/1/2	B	95	4	29*79
YTTO095003	56041/2	11B(OLD)	95	4	34*76
YTTO095004	56060,56040	11B	95	4	32*72
YTTO095005	56010	B	95	4	29*79
YTTO095006	56050	B(NEW)	95	4	29*72
YTTO095007	75020	2RZ	95	4	24*70
YTTO096001	54100/1	3L	96	4	29*74
YTTO096002	67020	1KZ-TE	96	4	34*73
YTTO096003	67030	1KZ	96	4	34*73
YTTO096004	67050	1KZ NEW	96	4	34*73
YTTO096005	30060	1KD	96	4	34*73
YTTO098001	57010	2B	98	4	29*79

YTP NO.	TOYOTA(13101-)	ENGINE	Bore Dia	No. of Cyl.	PIN
YTTO098002	57011,27020,57020	2B	98	4	29*79
YTTO098003	78700-71	2Z	98	4	32*77
YTTO099001	54120	5L	99.5	4	29*74
YTTO100001	66020	1FZ	100	6	26*63
YTTO100002	66040	1FZ	100	6	26*63
YTTO102001	58011/2	3B	102	4	32*84
YTTO102002	58020/1	13B	102	4	34*84
YTTO102003	58040/1	14B	102	4	32*72
YTTO102004	58050	3B	102	4	32*72
YTTO102005	58060	14BT	102	4	34*79
YTTO108001	58080/90	15B	108	4	34*73